


PV Module Unpacking Instructions



Remove the Stretch Wrapping Film if being used from the pallet using a cutter



Cut the strips on outer box (E.g. as Shown  marks in the image)



Lean the modules against a wall or a stand and ensure that they don't topple over



Remove the edge covers if available or separator sheet between panels or cling wrap sheet as applicable



Move the module from the pallet individually and keep them on the side. Ensure safe handling



Repeat the entire range of steps for the other pallets

PV Module Unpacking Instructions

Note:

While unloading and unpacking videography and photos are to be taken by customer. It is mandatory, to provide such evidence while customer observed any defects / damage from inside the package. Without such evidence any complaint regarding damage will not be considered.

If Packaging boxes are in defective or damage condition, then Mail Ritika Systems Private Limited, with the evidence as mentioned above for the damage. The E-mail is: info@ritikasystems.in

- Make sure you followed the stated Return Policy or as applicable
- Above packing specifications may change with/without prior notice.

Only fork-lift is recommended for unloading & movement of pallets. For any other means of unloading, contact Ritika Systems Private Limited



While unpacking modules from pallet, two persons are mandatory to handle the modules.
 When handling modules always use both hands and safety gloves.
 Do not carry modules on head.



Do not stack more than the maximum number of allowed pallets.
Never stack more than 2 pallets.



Do not use forklift truck directly when pallet found in broken or other issues regarding the pallet.



Do not step or stand on modules.
 Do not place any objects on modules.



Fragile! Module should be handled carefully.
 Do not place modules roughly on hard surface or on their corners.
 Do not drag modules over each other while unstacking.



The cardboard sheet and package material are recyclable.



Package and modules should be protected from excessive moisture (rain, snow, etc.) and must accordingly be stored under cover.
 If package and modules cannot be stored in warehouses or sheds, they must be carefully covered with tarpaulins.



Do not exceed rated load capacity of forklift. Only transport double stack pallet if it is well aligned. Do not collide with other object / pallet while transporting modules.
 Only use fork-lifts with long forks (at least 1.25 m or 4.0 feet) to move the packages stacking in the pallets.

Prepared By:
SANDEEP GUPTA
Approved & Issued By:
ARUN MONGA
Page 2 of 2